

Wifi Electronic Locks

wi800 and in120

There are two types of wifi locks installed on various doors throughout the DCC Main Campus and South Campuses.

wi800 wifi lock

Wi800's are installed on doors that are meant to remain locked at all times. The wi800 should remain in a locked position until an authorized identification card is presented at the lock sensor, which momentarily unlocks the lock. Single action egress from the inside is accomplished by simply using the door handle (there is no need to present an ID card from the inside).

Exterior of Door



The square is NOT a sensor.

Sensor. Hold ID card directly next to sensor.

Hard key will open door. Call Security.

Interior of Door



Nothing on interior

Always single action egress from room.

in120 wifi lock

The in120 can be placed in an unlocked position for offices that require customer service access to the space throughout the workday, for example, Human Resources and the Health Office. Because the lock can be left in an unlocked state, a button on the inside of the door can be pushed to manually lock the door in case of an emergency. Single action egress from the inside is accomplished by simply using the door handle (there is no need to present an ID card from the inside).

Exterior of Door



Green or Red: Good read or Bad read

Sensor. Hold ID card directly next to sensor. Present twice to remain unlocked.

Hard key will open door. Call Security.

Interior of Door



Press button to manually lock door.

Always single action egress from room.